

NOTE:

BIN PLATE TO BE INSTALLED ON BEGINNING RIGHT WINGWALL, DATE PLATE TO BE PLACED ON THE BEGINNING RIGHT AND END LEFT WINGWALLS

BIN & DATE PLATE NOT TO SCALE